

Installer manual
NIBE™ ERS 10-500
Ventilation heat exchanger

Table of Contents

1 Important information _____	4	10 Accessories _____	18
Safety information _____	4		
Serial number _____	4	11 Technical data _____	19
Recovery _____	4	Dimensions _____	19
Country specific information _____	4	Technical specifications _____	20
Contact information _____	5	Energy labelling _____	21
		Electrical circuit diagram _____	22
2 Delivery and handling _____	6	Index _____	23
Transport and storage _____	6		
Assembly _____	6		
Supplied components _____	6		
Removing the covers _____	7		
Removing parts of the insulation _____	7		
3 The ventilation heat exchanger design _____	8		
4 Pipe and ventilation connections _____	10		
Dimensions and pipe connections _____	10		
Mounting _____	10		
Condensation water drain _____	10		
General ventilation connections _____	11		
Preheating the outdoor air _____	11		
Ventilation flow _____	11		
Adjusting ventilation _____	11		
5 Electrical connection _____	12		
Connecting to main product _____	12		
6 Commissioning and adjusting _____	14		
Preparations _____	14		
Filling and venting _____	14		
Start-up and inspection _____	14		
7 Program settings _____	15		
Start guide _____	15		
Menu system _____	15		
8 Disturbances in comfort _____	16		
Info-menu _____	16		
Manage alarm _____	16		
Troubleshooting _____	16		
9 Service _____	17		
Water seal for condensation water _____	17		
Heat exchanger _____	17		

1 Important information

Safety information

This manual describes installation and service procedures for implementation by specialists.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Rights to make any design or technical modifications are reserved.

©NIBE 2016.

Symbols



NOTE

This symbol indicates danger to machine or person.



Caution

This symbol indicates important information about what you should observe when maintaining your installation.



TIP


This symbol indicates tips on how to facilitate using the product.

Marking

The CE marking means that NIBE ensures that the product meets all regulations that are placed on it based on relevant EU directives. The CE mark is obligatory for most products sold in the EU, regardless where they are made.

Serial number

The serial number can be found at the top right inside the front hatch.



Caution

Always give the product's serial number when reporting a fault.

Recovery



Leave the disposal of the packaging to the installer who installed the product or to special waste stations.

When disposing of the product, the constituent materials and components, such as compressors, fans, circulation pumps and circuit boards, must be disposed of at a special waste station or at a dealer who provides this type of service.

To access the separate components, refer to the section that shows the construction of the product. No special tools are required for access.

Improper disposal of the product by the user results in administrative penalties in accordance with current legislation.

Country specific information

Installer manual

This installer manual must be left with the customer.

Contact information

- AT KNV Energietechnik GmbH**, Gahberggasse 11, 4861 Schörfling
Tel: +43 (0)7662 8963-0 Fax: +43 (0)7662 8963-44 E-mail: mail@knv.at www.knv.at
- CH NIBE Wärmetechnik c/o ait Schweiz AG**, Industriepark, CH-6246 Altishofen
Tel: (52) 647 00 30 Fax: (52) 647 00 31 E-mail: info@nibe.ch www.nibe.ch
- CZ Druzstevni zavody Drazice s.r.o.**, Drazice 69, CZ - 294 71 Benatky nad Jizerou
Tel: +420 326 373 801 Fax: +420 326 373 803 E-mail: nibe@nibe.cz www.nibe.cz
- DE NIBE Systemtechnik GmbH**, Am Reiherpfahl 3, 29223 Celle
Tel: 05141/7546-0 Fax: 05141/7546-99 E-mail: info@nibe.de www.nibe.de
- DK Vølund Varmeteknik A/S**, Member of the Nibe Group, Brogårdsvej 7, 6920 Videbæk
Tel: 97 17 20 33 Fax: 97 17 29 33 E-mail: info@volundvt.dk www.volundvt.dk
- FI NIBE Energy Systems OY**, Juurakkotie 3, 01510 Vantaa
Puh: 09-274 697 0 Fax: 09-274 697 40 E-mail: info@nibe.fi www.nibe.fi
- FR NIBE Energy Systems France Sarl**, Zone industrielle RD 28, Rue du Pou du Ciel, 01600 Reyrieux
Tel : 04 74 00 92 92 Fax : 04 74 00 42 00 E-mail: info@nibe.fr www.nibe.fr
- GB NIBE Energy Systems Ltd**, 3C Broom Business Park, Bridge Way, Chesterfield S41 9QG
Tel: 0845 095 1200 Fax: 0845 095 1201 E-mail: info@nibe.co.uk www.nibe.co.uk
- NL NIBE Energietechnik B.V.**, Postbus 634, NL 4900 AP Oosterhout
Tel: 0168 477722 Fax: 0168 476998 E-mail: info@nibenl.nl www.nibenl.nl
- NO ABK AS**, Brobekkveien 80, 0582 Oslo, Postadresse: Postboks 64 Vollebekk, 0516 Oslo
Tel. sentralbord: +47 23 17 05 20 E-mail: post@abkklima.no www.nibeenergysystems.no
- PL NIBE-BIAWAR Sp. z o. o.** Aleja Jana Pawła II 57, 15-703 BIAŁYSTOK
Tel: 085 662 84 90 Fax: 085 662 84 14 E-mail: sekretariat@biawar.com.pl www.biawar.com.pl
- RU © "EVAN"** 17, per. Boynovskiy, Nizhny Novgorod
Tel./fax +7 831 419 57 06 E-mail: info@evan.ru www.nibe-evan.ru
- SE NIBE AB Sweden**, Box 14, Hannabadsvägen 5, SE-285 21 Markaryd
Tel: +46-(0)433-73 000 Fax: +46-(0)433-73 190 E-mail: info@nibe.se www.nibe.se

For countries not mention in this list, please contact Nibe Sweden or check www.nibe.eu for more information.

2 Delivery and handling

Transport and storage

ERS 10 should be transported and stored in the dry.


Assembly

ERS 10 is installed on the enclosed rail on a solid wall. Noise from the fans can be transferred to the rail.

- Install with its back to an outside wall, ideally in a room where noise does not matter, in order to eliminate noise problems. If this is not possible, avoid placing it against a wall behind a bedroom or other room where noise may be a problem.
- Wherever the unit is located, walls to sound sensitive rooms should be fitted with sound insulation.
- Because water comes from ERS 10, the condensation drain with the necessary water seal must be led to the internal drain.

Installation area


Leave free space of 800 mm in front of the product.



NOTE

Ensure that there is sufficient space (300 mm) above the exhaust air module for installing ventilation hoses.

Supplied components




Rail for wall mounting


Removing the covers

Front cover

1. Lift the front cover upwards slightly.
2. Pull the hatch towards yourself.



3. Pull the insulation straight out.




Removing parts of the insulation


Front insulation

The insulation in the front must be removed to access the internal parts.

1. Remove the air filter.
2. Slacken off the screws that hold the insulation in place.



3 The ventilation heat exchanger design



Pipe connections

XL31	Ventilation connection, exhaust air
XL32	Ventilation connection, extract air
XL33	Ventilation connection, supply air
XL34	Ventilation connection, outdoor air
XL40	Condensation water drain

Sensors etc.

BT20	Temperature sensor, exhaust air
BT21	Temperature sensor, extract air
BT22	Temperature sensor, supply air
BT23	Temperature sensor, outdoor air

Electrical components

AA5	Accessory card
EP26	Heat exchanger
UB1	Cable gland
W1	Cord with connection plug
W2	Control cable

Ventilation

EP26	Heat exchanger
GQ2	Fan, exhaust air
GQ3	Fan, supply air
HQ10	Air filter, exhaust air (Coarse filter class G4)
HQ11	Air filter, supply air (Fine filter class F7)
QN37	Bypass damper


Miscellaneous

PF1	Type plate
WM5	Condensation water trough

Designations in component locations according to standard IEC 81346-1 and 81346-2.

4 Pipe and ventilation connections


Dimensions and pipe connections



Mounting

When hanging on a wooden wall, a vibration damper is recommended to prevent vibration being transferred.

1. Install the enclosed bracket to the wall.
2. Install ERS 10 on the brackets.



Condensation water drain

ERS 10 can produce several litres of condensation water per day. It is therefore important that the condensation drain is correctly laid out and the unit is installed level.

Check that the water seal is airtight and firmly in position. The connection must be made so that the user can check that the water seal is functioning, without opening ERS 10.


Installation from the water seal and forward to the drain must be carried out with a necessary fall of 1 %. If the unit is installed in a cold area, the condensation water drain pipe must be insulated so that the condensation water in the pipe does not freeze. It is also recommended that the water seal is mounted in a heated area to guarantee that the water in the water seal does not freeze.

If it cannot be guaranteed that insulation will protect the condensation water drain pipe against frost, a thermostat controlled heating cable must be installed around the condensation water drain pipe.



NOTE

During operation there is a negative pressure in the unit which means that a water column of at least 100 mm must be guaranteed in the water seal.



General ventilation connections

Ventilation installation must be carried out in accordance with current norms and directives.

To prevent fan noise being transferred to the ventilation devices, install silencers in the ducts. This is especially important if there are ventilation devices in bedrooms.

The extract air and outdoor air ducts are to be insulated using diffusion-proof material (PE30) along their entire lengths. Ensure that the condensation insulation is sealed at any joints and/or at lead-in nipples, silencers, roof cowls or similar. Provision must be made for inspection and cleaning of the duct. Make sure that there are no reductions in cross-sectional area in the form of creases etc., since this will reduce the ventilation capacity. The air duct system must be a minimum of air tightness class B.

All joints in the ducting must be sealed to prevent leakage.

It is recommended that the outdoor air inlet be located on the north or east side of the house to achieve optimal comfort in the house.

When positioning the outdoor air and extract air hood/grille, bear in mind that the two air flows must not short circuit to prevent the exhaust air from being sucked in again.

Exhaust air duct /kitchen fan

Exhaust air duct (kitchen fan) must not be connected to ERS 10.


To prevent cooking odours from being led to the ERS 10, the distance between the kitchen fan and the exhaust air valve must be observed. The distance must not be less than 1.5 m, but may vary between different installations.

Always use a kitchen fan when cooking.



NOTE


A duct in a masonry chimney stack must not be used for extract air.



Preheating the outdoor air

If the extract air temperature is too low the supply air fan slows down to prevent the condensation water in the heat exchanger freezing.

To prevent this from happening too often in areas with colder climates, an electrical air heater EAH 10 (EB17) must be installed in the outdoor air duct as illustrated. This heats the incoming outdoor air so that the extract air temperature does not fall to the stated level.



The outdoor air sensor (BT23) in ERS 10 must be disconnected and replaced with the one supplied with EAH 10. See the Installation manual for EAH 10 for further instructions.

Ventilation flow

Connect ERS 10 so that all exhaust air except exhaust kitchen air (kitchen fan) passes the heat exchanger (EP26) in the heat pump. The lowest ventilation flow must comply with the applicable national standards. The supply air flow must be lower than the exhaust air flow to prevent over pressure in the house.

Ensure that the ventilation openings are not blocked. Set the ventilation capacity in the main product's menu system (menu 5.1.5).

Adjusting ventilation

To obtain the necessary air exchange in every room of the house, the exhaust air valve and the supply air inlet as well as the fans in the ventilation heat exchanger must be correctly positioned and adjusted.

Immediately after installation adjust the ventilation so that it is set according to the projected value of the house.

A defective ventilation installation may lead to reduced installation efficiency and thus poorer operating economy, and may result in moisture damage to the house.

5 Electrical connection

NOTE
 All electrical connections must be carried out by an authorised electrician.
 Electrical installation and wiring must be carried out in accordance with the stipulations in force.
 ERS 10 must not be powered during installation.

NOTE
 If the supply cable is damaged, only NIBE, its service representative or similar authorised person may replace it to prevent any danger and damage.


NOTE
 Communication and/or sensor cables to external connections must not be laid closer than 20 cm from high voltage cables, to prevent interference at any splices.

For electrical wiring diagram, see page 22.


Connecting to main product

If several accessories are to be connected, or are already connected, the following cards must be connected in series with the previous card.


Use cable type LiYY, EKKX or similar.



The communication cable (W2) in ERS 10 must be connected to the main product.




If more accessories are installed, ERS 10 must be connected last in the series, as illustrated.



TIP

See the main product's Installer Manual for the location of the input board (AA3).

The DIP switch (AA5-S2) must be set as follows.



6 Commissioning and adjusting

Preparations

- Check the miniature circuit-breaker (FA1) in the main product. It may have tripped during transportation.
- Check that the air filters are clean, they can become dirty after installation.

Filling and venting

- Check that there is water in the water seal, fill if necessary.

Start-up and inspection

Setting the ventilation

Ventilation must be set according to applicable standards. The supply air flow is adjusted to ensure a negative pressure. The settings are made in menus 5.1.5 and 5.1.6.

Even if ventilation is roughly set at installation it is important that a ventilation adjustment is ordered and permitted.



Caution


An incorrectly set ventilation flow can damage the house and may also increase energy consumption.




NOTE

Order a ventilation adjustment to complete the setting.

Ventilation capacity



Output, fans



7 Program settings

Program setting of ERS 10 can be performed via the start guide or directly in the menu system in the main product.



Caution

See the documentation for the main product.

Start guide

The start guide appears upon first start-up after heat pump installation, but is also found in menu 5.7.

Menu system

If you do not make all settings via the start guide or need to change any of the settings, this can be done in the menu system.

Menu 5.2.4 -system settings

Activating/deactivating of accessories.

Activate: "exhaust/supply air module".

Menu 5.3.12 - exhaust/supply air module

Settings specific to ERS 10.

"Lowest extract air temp.": Set the minimum extract air temperature to prevent the heat exchanger freezing. The supply air fan speed reduces if the extract air temperature at (BT21) is lower than the set value.

"Bypass at temperature": If a room sensor is installed, set the over-temperature at which the bypass damper (QN37) must open here.

"Months btwn filter alarms": Set how often the filter alarm must be displayed.



TIP

When ERS 10 is activated, the other ventilation menus will also light up.

8 Disturbances in comfort

In most cases, the main product notes a malfunction (a malfunction can lead to disturbance in comfort) and indicates this with alarms and shows action instructions in the display.

Info-menu

All the measurement values are gathered under menu 3.1 in the main product's menu system. Looking through the values in this menu can often simplify finding the source of the fault. See help menu or the main product's user manual for more information about menu 3.1.

Manage alarm

In the event of an alarm, some kind of malfunction has occurred, which is indicated by the status lamp changing from green continuously to red continuously. In addition, an alarm bell appears in the information window.



Alarm

In the event of an alarm with a red status lamp, a malfunction has occurred that the main product cannot remedy itself. By turning the control knob and pressing the OK button, you can see in the display what type of alarm it is and reset it. You can also choose to set the main product in aid mode.

info / action Here you can read what the alarm means and receive tips on what you can do to correct the problem that caused the alarm.

reset alarm In most cases it is enough to select "reset alarm" to correct the problem that caused the alarm. If a green light illuminates after selecting "reset alarm" the alarm has been remedied. If a red light is still visible and a menu called "alarm" is visible in the display, the problem that caused the alarm remains. If the alarm disappears and then returns, see the troubleshooting section (page 16).

aid mode "aid mode" is a type of emergency mode. This means that the heat pump produces heat and/or hot water despite there being some kind of problem with the heat pump. This can mean that the heat pump's compressor is not running. In this case the immersion heater produces heat and/or hot water.

Problems with ERS 10 do not affect the main product's operation. You therefore do not need to select "aid mode" in event of problems with ERS 10.



Caution

Selecting "aid mode" is not the same as correcting the problem that caused the alarm. The status lamp will therefore continue to be red.

Troubleshooting

If the operational interference is not shown in the display the following tips can be used:

Basic actions

Start by checking the following possible fault sources:

- That the main product is running and that the supply cable to ERS 10 is connected.
- Group and main fuses of the accommodation.
- The property's earth circuit breaker.
- The main product's fuses/temperature limiter.

High or low room temperature

- See Installer Manual for the main product.

Low or a lack of ventilation

- Level monitor (BL2) tripped.
 - Checking the condensation water drain and water seal.
- Filter blocked.
 - Clean or replace the filter.
- The ventilation is not adjusted.
 - Order/implement ventilation adjustment.
- Closed, too much choke or blocked ventilation device.
 - Check and clean the exhaust air devices.
- Fan speed in reduced mode.
 - Enter the main product's menu 1.2 and select "normal".
- External switch for changing the fan speed activated.
 - Check any external switches.
- Fan running slow because of low incoming outdoor air temperature.
 - Check the function and settings for the electrical air heater if installed.

High or distracting ventilation


- Filter blocked.
 - Clean or replace the filter.
- The ventilation is not adjusted.
 - Order/implement ventilation adjustment.
- Closed, too much choke or blocked ventilation device.
 - Check and clean the exhaust air devices.
- Fan speed in forced mode.
 - Enter the main product's menu 1.2 and select "normal".
- External switch for changing the fan speed activated.
 - Check any external switches.
- Silencers not correctly installed.
 - Check the silencers.

9 Service



NOTE

Always cut the power before opening ERS 10.



Water seal for condensation water

The water seal must be installed so that it can be checked by the user, without needing to open ERS 10.

The water seal may dry out during the hotter periods of the year when no condensation is generated. Therefore, before the cold periods of the year, the condensation water drain must be checked for blockage due to dirt and filled with water.

Pour approx. one litre of water into the water seal and check that it runs through unobstructed.

The water seal must not dry out during those months of the year that condensation is created because, due to the negative pressure in the unit, air will be sucked into the unit which will then prevent the condensation water from running off. ERS 10 can produce several litres of condensation water each day. If the condensation water drain does not function, water may cause damage inside the house.

Heat exchanger

The heat exchanger (EP26) must be inspected at regular intervals. Every other year is recommended.

If it is dirty, it must be removed and vacuumed without touching the fins.

Press gently from behind when removing the heat exchanger. Bear in mind that the fins are sensitive and easily damaged.



NOTE

Do not damage the fins. If the fins are damaged the output may be reduced.

10 Accessories


Electrical air heater EAH 10

This accessory heats the incoming outdoor air so that the extract air temperature is not too low.

Part no. 067 567

11 Technical data

Dimensions




Technical specifications

		ERS 10
Electrical data		
Supply voltage		230 V ~ 50 Hz
Fuse	A	10
Driving power fan	W	170 x 2
Enclosure class		IP21
Connections		
Ventilation connection	mm	Ø160
Connection, condensation water drain	mm	Ø32
Noise level		
Sound power level ($L_{W(A)}$)	dB(A)	48
Dimensions and weight		
Length, supply cable	m	2.4
Length, control cable	m	2.0
Height	mm	900
Width	mm	600
Depth	mm	612
Weight	kg	40
Part no.		066 079

1 287 m³/h at 50 Pa

Temperature efficiency


Efficiency (%)



Energy labelling

Supplier		NIBE
Model		ERS 10-500
Specific energy consumption (SEC)	kWh/(m ² year)	Average: -34.03 Cold: -71.47 Warm: -9.95
Energy efficiency class		A
Declared typology		RVU, Bidirectional
Type of drive		Variable speed drive
Type of heat recovery system		Recuperative
Thermal efficiency of heat recovery		86
Maximum air flow rate	m ³ /h	410
Electric power input of the fan drive at maximum flow rate	W	255
Sound power level (LWA)	dB	48
Reference flow rate	m ³ /s	0.0797
Reference pressure difference	Pa	50
Specific power input (SPI)	W/m ³ /h	0.36
Control factor and control typology		Clock control (0.95)
External leakage rates	%	Intern: 2.2 Extern: 1.3
Information about filter warning		See user manual.
Information about supply/exhaust grilles in the facade		See section General ventilation connections on page 11.
Information about pre-/disassembly		See section Recovery on page 4. This installer manual can also be accessed at www.nibe.eu .
The annual electricity consumption	kWh/year	456
Annual heating saved, kWh primary energy per year	kWh prim/year	Average: 4,477 Cold: 8,758 Warm: 2,024

Electrical circuit diagram



12 Item register

Item register

A

- Accessories, 18
- Adjusting ventilation, 11
- Alarm, 16

C

- Contact information, 5

D

- Disturbances in comfort, 16
 - Alarm, 16
 - Manage alarm, 16
 - Troubleshooting, 16

E

- Energy labelling, 21
- Exhaust air duct, 11

I

- Important information, 4
 - Recovery, 4

M

- Manage alarm, 16
- Marking, 4

P

- Pipe and ventilation connections
 - Adjusting ventilation, 11
 - Exhaust air duct, 11
 - Ventilation flow, 11

S

- Safety information
 - Contact information, 5
 - Marking, 4
 - Symbols, 4
- Start-up and inspection
 - Setting the ventilation, 14
- Symbols, 4


T

- The design of the exhaust air module, 8
 - List of components, 9
- Troubleshooting, 16

V

- Ventilation flow, 11

NIBE AB Sweden
Hannabadsvägen 5
Box 14
SE-285 21 Markaryd
info@nibe.se
www.nibe.eu



331802